

### CME TACTILE INSTALLATION INSTRUCTIONS

- 1) Place the tiles or template on the curb ramp / footpath as per AS1428.1 and trace the perimeter with a thin permanent marker.
- 2) Set the tiles aside and using a 100mm diamond cup grinder, lightly scour the concrete within the marked location and in correspondence with the location requiring adhesive as indicated on backside of tile.
- 3) Using a template or as marked, drill fixing holes down 80mm with a hammer drill & 6.5mm masonry bit.
- 4) Insert supplied fixing plugs into the drilled holes and tap down flush to concrete surface then thoroughly clean the working area of all dust with a brush or broom
- 5) Apply adhesive (Sikaflex-11FC or Bostik Seal'n'Flex FC) to back of the tile as indicated. The first bead should be applied thin, 12mm from the perimeter edge and a second thicker bead applied 25mm inside of the first.
- 6) Position the tile onto the curb/ramp footpath pass the marked lines and holes and press down firmly
- 7) Insert the supplied stainless steel screws through the tile into the plugs and torque down in a cross pattern using a cordless drill until secure making sure the tile is even and square.

